



# Installation of Your Range

**NOTE:** Range installation should be performed by a licensed and bonded electrician and gas plumber.

## STEP 1

Connect the range's electrical circuit.

- Remove the small cover(s) from the back of the range
- Red connector: Connect the wires as shown. If your range has 2 connectors, connect **ONLY** to the main connector that has the diagram next to it. No diagram = no connection. The connector without a diagram is simply used as a "relay" to feed all components.
- Black connector: connect ground wire to the range's chassis. Connect L1 – N – L2 to the block (neutral in the middle)



Wiring diagram – connect power cord

## STEP 2

Connect the gas line. Use a 4' flexible line rated for use with NG or LP fuel of the correct inner diameter. Input pressure must be no more than 0.5psi.

